

THANK YOU FOR YOUR PURCHASE

Directions for use



1. Dam on right side. Now to assemble, place wood part under repair, then one rubber band to hold material in groove. Metal part is now fitted in groove and your second rubber band will hold both parts together. To commence darning, stitch thread to material, pass around one hook bringing thread down to fasten on to stocking. Repeat this over each hook till hole is covered. NOTE-It is not necessary to use all hooks, use enough to cover repair.



2. Run EYE of needle through passage between rows of threads, press needle down before withdrawing. this will close the weave, now fasten thread to stocking. Slide finger along chain of hooks to change rows, continue repeating this movement till dam is completed.



3. Dam now showing needle completing last row of threads.



4. Now remove rubber band, unhook metal part from threads and as shown above, fasten each loop to stocking.