


<b>包装信息</b> 型号: T-03 成品尺寸: 110*160MM 材质: 128g铜版纸, 折页 工艺: 四色印刷 版本号: V1. 1-20230309	<b>备注信息</b> 三折页
--	--------------------


T-03


Karaoke Machine





Note: Please read the instruction manual carefully before use.

Product Diagram





①  Short press the button to turn on/off the music only(Accompaniment Mode), long press to turn on the microphone priority function.


②  Short press the button to switch 6 light modes.The LED lights of karaoke machine will flash with the rhythm. Long press to turn off the lights.


③  Short press to switch Bluetooth mode and FM mode.

1


④  Short press the button to play previous song. Long press it for fast reverse.


⑤  In Bluetooth mode, short press the button to play/stop music, long press it to disconnect.If you have two karaoke machines, double-click the button, and connect the machines with your device via bluetooth, TWS function can be used.


⑥  Press the button to play the next song. Long press it for fast forward.

⑦  Press the button to turn on/off the machine.


FM Mode:

Short press  button to switch the FM mode.

Short press  button to switch stations.

long press  button to search stations automatically.


2



⑧ *Mic Echo*: Rotate the knob to adjust mic echo effect.

⑨ *Mic Volume*: Rotate the knob to control mic volume.

⑩ *Speaker Volume*: Rotate the knob to control karaoke speaker volume.



⑪ *Charging Port*: Use the included USB cable and 5V charger (not include) to charge the karaoke machine.


⑫ *USB Port*: Insert USB flash drive to play MP3 files in it.

⑬ *TF Card Slot*: Insert TF card to play MP3 files in it.

⑭ *Accompaniment/Audio Port*: Import accompaniment music and AUX.


⑮ *Mic/Instrument Port*: Supports wired microphone and instrument audio input.

3




①

②

Please notice each wireless microphone needs 2 AA  (not include).

Cautions

◆ When receiving the product,please use the included USB charging cable and 5V charger (not include) to charge the karaoke machine for 4-5h.

◆ Since there is a built-in high capacity  in karaoke machine,please keep the product away from high temperature environment and avoid exposure to sunlight for long time.

◆ To avoid strident sound,please do not put the microphones too close to the speaker during use.

◆ If have any questions,do not worry. Please go to your order and click "Contact Seller",we'll do our best to help you!

4

Packing List

Karaoke Machine \*1

Wireless Microphone \*2

USB Charging Cable \*1

Shoulder Strap \*1

Technical Information

Model	T-03
Bluetooth Name	T-03
Bluetooth Transmission	<=10m (no obstacle distance)
Input Power	5V/1A
Frequency	80HZ-18KHz
Loudspeaker	6.5 inches 15 Watt

5

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.

- - Increase the separation between the equipment and receiver.

- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

6

IC warning:

This device contains licence-exempt transmitter(s)/receiver(s)/ that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment; To maintain compliance with IC's RF Exposure guidelines, This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Déclaration de l'ISED Canada:  
Cet appareil contient des tasmittre (s) / récepteur (s) sans licence / conformes à l'innovationRSS exemptes de licence de Sciences et Développement économique Canada. L'opération est sous réserve des deux conditions suivantes:

1) cet appareil ne peut pas causer d'interférences et

2) ce dispositif doit accepter toute interférence, y compris peut provoquer le fonctionnement indésirable de l'appareil.

Exposition aux rayonnements : Cet équipement est conforme aux radiations du Canada limites d'exposition pour un environnement incontrôlé noncé d'exposition RF Pour maintenir le respect des guides d'exposition RF d'IC, Cet appareil et ses antennes ne doivent pas être co-localisé ou en opération en conjonction avec toute autre antenne ou émetteur.

7