


VACUUM SEALER

USER MANUAL



Vacuum Sealer
Sellador Al Vacio
Scelleuse Sous Vide

真空机
Sigillatrice Sottovuoto
Vakuumversiegelung




Step-by-Step Guide

1. Place your food in the bag and zip it tightly. Make sure there are no gaps.
2. Lightly twist the cap to the right and remove it.
3. Place the vacuum sealer on the vacuum valve.
4. Press the button to turn on the device. Once the bag is vacuum sealed, the device automatically shuts off.
5. Detach the device from the vacuum valve.
6. Repeat the process to vacuum seal more bags. Otherwise, put the cap on and store it.

English

Technical Specs

Material:	ABS+PC
Battery capacity:	1200mAH
Charger Type:	USB Type C
Product Size:	20.5cm x 4.7cm
Weight:	237g
Voltage:	5V



Troubleshooting

Problem: The device is in the correct position, and is working, but the bag won't vacuum seal.

Solution: Check if the bag is zipped completely. Use the zipper clip that comes with the device to ensure the proper seal.

Problem: The device is not turning on or it's not powerful.

Solution: Fully charge the device for 2 hours.

Problem: The device sucked in liquid.

Solution: Remove the silicone protector from the pump and wipe the valve thoroughly with the dry cloth. Let it sit for a couple hours, and do not turn on the device.

Additional Bags

Running low? Get the bags delivered right to your door! Scan the code below to check our bag bundles. The best part? We offer free shipping on all orders!



Shop
Vacuum Bags

Assistance

Should you have any questions or concerns, need assistance with the product, please feel free to reach out to us at help@chefpreserve.com or **scan the code below**. We're always happy to help!



"Contact Us"
Page

chef
preserve

www.chefpreserve.com